

VCRC Carbon Products

VCRC products should always be installed by a trained bicycle mechanic. Failure to install parts properly could result in injury and may also void warranty.

All carbon parts should be torqued correctly. The following guide list will assist you:

- Carbon Stems- torque bolts to 6nm.
- Carbon Handlebars- torque stem bolts to 6nm
- Carbon Seatposts- torque seatpost clamp bolts to 6nm

Carbon parts should also be visually checked for cracks and or failures periodically.

Under NO CIRCUMSTANCES should a VCRC/Velo Carbon part be cut or modified in any way. This will not only void the warranty immediately, but it can make the part unsafe to ride.

VCRC Bike, Jan. 2003